

DISMOUNTING & STORAGE

SNOWBLOWER DISMOUNTING



WARNING



TO PREVENT INJURIES:

Stop the motor.

Apply parking brakes.

Remove the ignition key.

Disconnect the wire from the spark plug(s) and keep away from spark plug(s) to prevent accidental starting.

- a) Remove hair pin from handle tube and remove handle.
- b) Disconnect the driveline from tractor's P.T.O. by sliding back the collar on the yoke then pull the driveline out.
- c) Detach the snowblower by lifting up the spring locks on quick hitch and pulling back the snowblower.

SUBFRAME DISMOUNTING

See the subframe owner's manual for dismounting instructions.

END OF SEASON STORAGE

- a) Clean snowblower and subframe thoroughly and repaint all parts from which paint has worn.
- b) List the replacement parts that will be needed for the next season.
- c) Store the snowblower and the subframe in a dry place.
- d) Follow the instructions in the Lubrication section.