

# OPERATION

## **GENERAL SWEEPING**

Minimize dust by reducing brush speed and by sweeping after rain or on a day with high moisture.

## **SNOW SWEEPING**

Adjust the gauge (item 2) to be even with the top of gear box frame. The broom works well for light snow removal.

Sweep with the wind blowing in the direction of broom discharge (wind in your back).

**NOTE:** Foreign objects in the snow may be thrown faster than the snow itself.

Frequently clean the snow and ice accumulation from the top and bottom of the broom hood.


## **LAWN DETHATCHING AND LEAF RAKING:**

Lower the broom on a hard surface and lift the brush 1" from the ground by turning the adjusting screw clockwise. The brush is supported by dolly wheels. This adjustment is normally satisfactory but you may raise or lower depending upon grass height.


Low brush speed and ground speed is best for lawn dethatching and leaf raking.

Never sweep with the sides of bristles!

Sweep with the tips!  
Do not mop!



Too much pressure=  
Shortens brush life!



Flick action

Road surface